



SGK-05

TGB input seal replacement


Parts list




SG350A93-3307-00
TGB seal holder extractor



SG350A93-3308-00
Exchange seal / seal support



SG350A93-3205-00
Lock wrench



SG350A93-3305-20
TGB wrench
